




EXPLODED VIEW, PARTS AND PRICE LIST

Model 140, 147 & 1400


1953-1956




1956-1962



1962-1973



1973-1978




This parts and price list is intended to be an informational guide in ordering Crosman parts. It is not instructional material and we therefore assume no responsibility for those who use same without proper factory training.

REPRINT 7/93

CROSMAN AIRGUNS
Rt. 5&20 East Bloomfield, N.Y. 14443

FIGURE No. II
OLD

Discontinued Dec. 1971



OLD

FIG. No. 1



OLD

Discontinued Dec. 1968

USED ON
MCOCUS
140
147


MODEL 140 SEAL KIT

- 140-075
- 130-033
- 130-029
- 130-034
- 130-035
- 140-058
- 140-070
- 1400A029
- 140-063
- 101-043



MODEL 1400 SEAL KIT

- 140-075
- 130-033
- 1930-012
- 130-035
- 130-034
- 1930-016
- 140-058
- 140-070
- 1400A029
- 101-043



*Factory Assembly Only

Sold only with 1400-028*
Not Available

Not Available

Not Available