



EXPLODED VIEW PARTS LIST

397
BOLT ACTION PUMP
AIR RIFLE
.177 (4.5mm) cal.

CROSMAN CORPORATION
RT 5 & 20
EAST BLOOMFIELD, NY 14443

Phone: 1-800-724-7486
Parts Order Fax: 585-657-5405

B-397-CP

MODEL 397

<u>PART NUMBER</u>	<u>DESCRIPTION</u>
10804	CROSS HEAD PIN
1322-056	CHECK VALVE
2200A032	STRIKER SPRING
38-117	SCREW
397-001	MUZZLE CAP
397-002	MUZZLE CAP PIN
397-005	FOREARM PIN
397-006	FOREARM STOP
397-012	BARREL ASSY.
397-025	RUBBER PISTON
397-026	GRIP BASE
397-027	REAR SIGHT ASSEMBLY
397-028	SIGHT BASE
397-029	SIGHT ARM
397-030	ELEVATION SCREW
397-031	WINDAGE SCREW
397-032	VALVE ASSEMBLY
397-034	INLET VALVE BODY
397-035	VALVE SPRING
397-036	O-RING
397-037	O-RING
397-038	EXHAUST VALVE ASSEMBLY
397-041	SCREW
397-042	STOCK LUG
397-044	BOLT LOCKING LUG
397-046	TRIGGER ASSEMBLY
397-047	LEFT TRIGGER CASE
397-049	TRIGGER
397-050	PIN
397-051	SEAR
397-054	BOLT ASSEMBLY
397-058	PLATED CAM FACE COVER
397-059	SCREW
397-060	CAM FACE
397-061	SCREW
397-062	O-RING
397-063	EXHAUST VALVE BODY
397-064	GUIDE PIN
397-065	BOLT ASSEMBLY
397A004	BLACK LEVER LINK ASSEMBLY
397A020	PISTON ROD ASSEMBLY
397A048	RIGHT TRIGGER CASE
397A052	SEAR SPRING
760A017	SAFETY
766-091	SPRING
CB9-003	FOREARM
CB9A011	STOCK
CB9B002	FOREARM ASSEMBLY
G397-019	STRIKER
JTX-080	BALL LOCK O-RING

THIS PARTS LIST IS INTENDED TO BE AN INFORMATIONAL GUIDE IN ORDERING PARTS. IT IS NOT INSTRUCTIONAL MATERIAL. AN WE THEREFORE ASSUME NO RESPONSIBILITY FOR THOSE WHO USE SAME WITHOUT PROPER FACTORY TRAINING.


PLEASE ORDER BY PART NUMBER AND DESCRIPTION

CHECK OR MONEY ORDER FOR THE TOTAL PRICE MUST ACCOMPANY THE ORDER

UPDATED 4/19/05 B397EVP3

FOR CURRENT PRICES CONTACT CROSMAN CORPORATION AT 800-724-7486 OR VISIT OUR WEBSITE WWW.CROSMAN.COM

MODEL NO.
397



B397EVP3
April 19, 2005