



EXPLODED VIEW & PARTSLIST

MODELS RNP77 & RNP22 NITRO PISTON AIR RIFLES



Manufacture Start Date: 12/11/09

Last Update: 4/30/10

CROSMAN CORPORATION
RT 5 & 20
EAST BLOOMFIELD, NY 14443
Phone: 1-800-724-7486
Parts Order Fax: 585-657-5405
www.crosman.com

- This EVP and parts list is intended to be an informational guide in ordering parts. It is not instructional material and we therefore assume no responsibility for those who use the same without proper factory training.
- Please order by part number and description.
- Check or money order for the total price must accompany the order.
- For current prices contact Crosman Corporation at 1-800-724-7486 or visit our website www.crosman.com

PART LIST, MODELS RNP77, RNP22, ELS77, ELS22 (Digital Camo & Carbon Stock Versions)

Manufacture Start Date: 12/11/09

	PART NUMBER	DESCRIPTION
1	CRS5177-028	Cover, Tube
2	JTX-073	Screw, Sight
3	ELS-009	Shroud Cone
4	397-036	O-Ring (2x)
5	ELS-008	Shroud
6	ELS-007	Shroud Cap
7	ELS-016	Plug Pin, Dia .312 X 1.312
8	ELS-004	Tube Plug
9	ELS-006	Guide, Piston
10	ELS-011	Cushion Gas Spring
11*	ELS-012	Gas Spring *
12*	ELS-013	Piston *
13	CRS5177-012	Seal, Piston
14	RNP-021	Compression Tube (RNP)
	ELS-021	Compression Tube (ELS)
15	CRS5177-033	Pin, Detent
16	CRS5177-015	Screw, Pivot
17	2300-007	Set Screw, 6-32 X 3/16
18	CRS5177A013	O-Ring
19	CRS5177-017	Spacer, Breach (2x)
20	CRS5177-061	Pin, Knurled
21	CRS5177A069	Stock Brace
22	CRS5177-027	Stock Lug
23	ELS-100	Trigger Assembly (Page 4)
23A	CRS5177A024	Safety
23B	CRS5177A023	Secondary Sear
23C	CRS5177-070	Spacer, Sear (2x)
23D	CRS5177A022	Primary Sear
23E	CRS5177-046	Spring, Trigger
23F	CRS5177-035	Pin, Safety (2x)
23G	CRS5177-043	E-Ring (5x)
23H	CRS5177-038	Pin, Trigger
23J	CRS5177C047	Spring, Safety
23K	CRS5177-001	Trigger Pack Housing
23L	ELS-014	Screw
23M	ELS-025	Trigger
24	CRS5177-057	Spring, Beartrap
25	CRS5177-043	E-Ring
26	CRS5177-056	Lever, Beartrap
27	CRS5177A066	Screw, Stock (3x)

	PART NUMBER	DESCRIPTION
28	CRS5177-034	Detent
29	ELS-005	Spring, Detent
30	CRS5177-042	Assembly, Lever
31	CRS5177-014	Pivot Sleeve
32*	RNP-103	Barrel/Breach Asy. (.177 RNP)
	RNP-105	Barrel/Breach Asy. (.22 RNP)
	ELS-103	Barrel/Breach Asy. (.177 ELS)
	ELS-105	Barrel/Breach Asy. (.22 ELS)
33	ELS-112	Stock (Carbon Fiber)
	ELS-111	Stock (Digital Camo)
34	CRS5177-067	Screw, Trigger Guard
35	CRS5177-032	Trigger Guard

UNIQUE PARTS

14-COMPRESSION TUBE ASSEMBLY		
	PART NUMBER	Model
14	RNP-021	RNP77 & DC, RNP22 & DC
	ELS-021	ELS77 & DC, ELS22 & DC
32-BARREL BREACH ASSEMBLY		
	PART NUMBER	Model
32	RNP-103	RNP77, RNP77DC
	RNP-105	RNP22, RNP22DC
	ELS-103	ELS177, ELS177DC
	ELS-105	ELS122, ELS177DC
33-STOCK ASSEMBLY		
	PART NUMBER	Model
33	ELS-112	RNP77, RNP22, ELS77, ELS22
	ELS-111	RNP77DC, RNP22DC, ELS77DC, ELS22DC

VARIANT MODELS

* See next page for detuned & other variant model unique parts

PART LIST, VARIANT MODELS 5-RNP77, 6-RNP77, 6-RNP22, 8-RNP77

VARIANT UNIQUE PARTS

5-RNP77		
	PART NUMBER	Description
11	5-RNP-012	Gas Spring
12	8-RNP-013	Piston (Detuned)
32	5-RNP-103	Barrel/Breach Asy. .177

6-RNP77		
	PART NUMBER	Description
11	6-RNP-017	Gas Spring
12	8-RNP-013	Piston (Detuned)
32	6-RNP-103	Barrel/Breach Asy. .177

6-RNP22		
	PART NUMBER	Description
11	6-RNP-012	Gas Spring
32	6-RNP-105	Barrel/Breach Asy. .22

8-RNP77		
	PART NUMBER	Description
11	8-RNP-012	Gas Spring
12	8-RNP-013	Piston (Detuned)
32	8-RNP-103	Barrel/Breach Asy. .177



