


# EXPLODED VIEW AND PARTS LIST

## Model 70

Manufacturing Date 1973 To 1980




This manual is intended as an informational guide in servicing Crosman products. It is not instructional material and we therefore assume no responsibility for those who use same without proper factory training.

Reprint 3/90

**CROSMAN AIRGUNS**

Rt. 5&20 East Bloomfield, N.Y. 14443



Seal Kit  
 70-045  
 38-128  
 20-110