


EXPLODED VIEW, PARTS AND PRICE LIST MODEL 1861

Manufactured 1981-1985

This parts and price list is intended to be an informational guide in ordering Crosman parts. It is not instructional material and we therefore assume no responsibility for those who use same without proper factory training.

Reprint 7/92

CROSMAN AIRGUNS
Rt. 5&20 East Bloomfield, N.Y. 14443



SEAL KIT

1861A037

MODEL 1861 ASSEMBLIES AND PARTS LISTS

PART #	DESCRIPTION	QTY	PRICE	PART #	DESCRIPTION	QTY	PRICE
36-009	Grip Assembly R.H.	1		1861A043	Cylinder Assembly	1	
36-012	Trigger Pin	1		1861-044	Frame Screw Front	2	
38A027	Piercing Pin	1		1861-045	Frame Screw Rear	2	
38-028	Piercing Screen	1		1861A046	Barrel Sleeve	1	
38-128	End Seal	1		1861A047	Barrel Sleeve Sp.	1	
45-037	Grip Screw	1		1861-048	Barrel Set Screw	1	
70-057	Washer	1		1861-050	Hammer Screw	1	
140-058	O-Ring	1		1861-053	Cylinder Plate	1	
338-041	Guide Collar	1		1861-055	Trigger Assembly	1	
1861A026	Cover	1		1861A057	Frame & Piercing Assy	1	
1861A027	Valve Body	1		1861-058	Cylinder Detent	1	
1861A031	Powerlet Cover	1		1861A059	Safety	1	
1861-033	Hammer Spring	1		1861-060	Safety Spring	1	
1861B035	BB Pusher	1		1861-061	Valve Spring	1	
1861-036	Valve Stem Assembly	1		1861-062	Grip L.H.	1	
1861A037	Valve Assembly	1		1861-063	Valve Body Sleeve	1	
1861B039	Barrel Assembly	1		1861-064	Detent Spring	1	
1861-040	Hammer Assembly	1		1861-066	Trigger Spring	1	

without notice. Check or money order in amount of total purchase must accompany parts order. Order by part number and description. Prices subject to change

TO BE USED AS REFERENCE GUIDE ONLY